1105

Turning Equipment On

Turn on in any order:

1. Document Camera
2. Computer
3. VCR
4. Video Projector
5. Sound Amplifier/Speakers

Switching Between Sources:

(NOTE: Computer runs through Document Camera. Document Camera ***must*** be on to see Computer)

From Computer or Document Camera to VCR:

1. (To VCR)Switch Projector to "*Video*" with the "**Input**" button on the remote to the Projector.

From VCR to Computer or Document Camera:

1. (To Document Camera) With Document Camera on "*Internal*," switch Video Projector to "*Computer*" with the "**Input**" button on the remote to the Projector.
2. (To Computer) With Projector on "*Computer*," switch Document Camera to "*Ext 1*" with the "**Int/Ext**" button on the front of the Document Camera.

Turning Equipment Off

Turn off in any order:

1. Sound Amplifier
2. Video Projector
3. VCR
4. Computer
5. Document Camera

In case of emergency, call Media Services at x3295.